PARKBAI: PARKING SENSOR SOURCE CODE

```
#include <ESP8266WiFi.h>
#include "FirebaseESP8266.h"
#include <NewPing.h>
#define FIREBASE_HOST "your firebase Realtime database link here"
#define FIREBASE AUTH "your firebase Realtime database key here "
// Replace with your network credentials
const char* ssid = "your ssid name here";
const char* password = " your ssid password here ";
#define TRIGGER_PIN D5
#define ECHO_PIN D6
#define MAX_DISTANCE 396.0
NewPing sonar(TRIGGER_PIN, ECHO_PIN, MAX_DISTANCE); //Max distance 20 cm
//const int ledPin = D7;
FirebaseConfig config;
FirebaseAuth auth;
FirebaseData firebaseData;
FirebaseJson json;
String ownerUID = "bFnYTNgnXMYLrwwjqDoxzreu7Rn2";
void setup() {
Serial.begin(9600);
//pinMode(ledPin, OUTPUT);
// Connect to WiFi network
```

```
WiFi.begin(ssid, password);
 while (WiFi.status() != WL_CONNECTED) {
  delay(1000);
  Serial.println(".");
}
 Serial.println("Successfully connected.");
 Serial.print("ESP Board MAC Address:");
 Serial.println(WiFi.macAddress());
 Serial.print("http://");
 Serial.print(WiFi.localIP());
config.database_url = FIREBASE_HOST;
 config.signer.tokens.legacy_token = FIREBASE_AUTH;
 Firebase.reconnectWiFi(true);
 Firebase.begin(&config, &auth);
//Firebase.begin(FIREBASE_HOST, FIREBASE_AUTH);
}
void loop() {
delay(100);
 unsigned int distance_cm = sonar.ping_cm();
 unsigned int distance_inches = distance_cm / 2.54; // CENTIMETER TO INCHES
 unsigned int detectOccupied = 3.0;
 unsigned int detectImproperPark1 = 4.0;
 unsigned int detectImproperPark2 = 7.0;
 unsigned int detectVacant = 8.0;
 Serial.print("Distance: ");
 Serial.print(distance_inches);
 Serial.println(" inches");
```

```
json.set("parking_number", 1);
json.set("parking_section", "A");
 if (distance_inches <= detectOccupied) {</pre>
  //(ledPin, HIGH);
  Serial.println("OCCUPIED");
  json.set("parking_space", "OCCUPIED");
  Firebase.updateNode(firebaseData, "PARK_OWNER/" + ownerUID + "/PARKING_AREA/A01", json);
 } else if (distance_inches >= detectImproperPark1 && distance_inches < detectImproperPark2) {
  //digitalWrite(ledPin, HIGH);
  Serial.println("IMPROPER PARK");
  json.set("parking_space", "IMPROPER PARK");
  Firebase.updateNode(firebaseData, "PARK_OWNER/" + ownerUID + "/PARKING_AREA/A01", json);
}
 else if (distance_inches >= detectVacant){
  //digitalWrite(ledPin, LOW);
  Serial.println("VACANT");
  json.set("parking_space", "VACANT");
  Firebase.updateNode(firebaseData, "PARK_OWNER/" + ownerUID + "/PARKING_AREA/A01", json);
}
}
```